### **DNL Calculator**

The Day/Night Noise Level Calculator is an electronic assessment tool that calculates the Day/Night Noise Level (DNL) from roadway and railway traffic. For more information on using the DNL calculator, view the **Day/Night Noise Level Calculator Electronic Assessment Tool Overview (/programs/environmental-review/daynight-noise-level-electronic-assessment-tool/)**.

#### Guidelines

- To display the Road and/or Rail DNL calculator(s), click on the "Add Road Source" and/or "Add Rail Source" button(s) below.
- All Road and Rail input values must be positive non-decimal numbers.
- All Road and/or Rail DNL value(s) must be calculated separately before calculating the Site DNL.
- All checkboxes that apply must be checked for vehicles and trains in the tables' headers.
- **Note #1:** Tooltips, containing field specific information, have been added in this tool and may be accessed by hovering over all the respective data fields (site identification, roadway and railway assessment, DNL calculation results, roadway and railway input variables) with the mouse.
- Note #2: DNL Calculator assumes roadway data is always entered.

### **DNL Calculator**

Site ID	South Bascom
Record Date	10/29/2020
User's Name	

Road # 1 Name:	South Bascom Avenue

#### Road #1

Vehicle Type	Cars 🗹	Medium Trucks 🗹	Heavy Trucks 🗸
Effective Distance	70	70	70
Distance to Stop Sign	350	350	350
Average Speed	40	40	40
Average Daily Trips (ADT)	33800	1	1
Night Fraction of ADT	5	0	0
Road Gradient (%)			0
Vehicle DNL	64	27	39
Calculate Road #1 DNL	64	Reset	

Loud Impulse Sounds?

Combined DNL for all Road and Rail sources	0
Combined DNL including Airport	
Site DNL with Loud Impulse Sound	
Calculate Reset	

# **Mitigation Options**

If your site DNL is in Excess of 65 decibels, your options are:

- No Action Alternative: Cancel the project at this location
- Other Reasonable Alternatives: Choose an alternate site
- Mitigation
  - Contact your Field or Regional Environmental Officer (/programs/environmental-review/hud-environmental-staff-contacts/)
  - Increase mitigation in the building walls (only effective if no outdoor, noise sensitive areas)
  - Reconfigure the site plan to increase the distance between the noise source and noise-sensitive uses
  - Incorporate natural or man-made barriers. See *The Noise Guidebook (/resource/313/hud-noise-guidebook/)*
  - Construct noise barrier. See the Barrier Performance Module (/programs/environmental-review/bpm-calculator/)

## **Tools and Guidance**

Day/Night Noise Level Assessment Tool User Guide (/resource/3822/day-night-noise-level-assessment-tool-user-guide/)

Day/Night Noise Level Assessment Tool Flowcharts (/resource/3823/day-night-noise-level-assessment-tool-flowcharts/)

### **DNL Calculator**

The Day/Night Noise Level Calculator is an electronic assessment tool that calculates the Day/Night Noise Level (DNL) from roadway and railway traffic. For more information on using the DNL calculator, view the **Day/Night Noise Level Calculator Electronic Assessment Tool Overview (/programs/environmental-review/daynight-noise-level-electronic-assessment-tool/)**.

#### Guidelines

- To display the Road and/or Rail DNL calculator(s), click on the "Add Road Source" and/or "Add Rail Source" button(s) below.
- All Road and Rail input values must be positive non-decimal numbers.
- All Road and/or Rail DNL value(s) must be calculated separately before calculating the Site DNL.
- All checkboxes that apply must be checked for vehicles and trains in the tables' headers.
- **Note #1:** Tooltips, containing field specific information, have been added in this tool and may be accessed by hovering over all the respective data fields (site identification, roadway and railway assessment, DNL calculation results, roadway and railway input variables) with the mouse.
- Note #2: DNL Calculator assumes roadway data is always entered.

### **DNL Calculator**

Site ID	South Bascom
Record Date	10/29/2020
User's Name	

Road # 1 Name:	South Bascom Avenue

#### Road #1

Vehicle Type	Cars 🗹	Medium Trucks 🗹	Heavy Trucks 🗸
Effective Distance	70	70	70
Distance to Stop Sign	350	350	350
Average Speed	40	40	40
Average Daily Trips (ADT)	34162	1	1
Night Fraction of ADT	5	0	0
Road Gradient (%)			0
Vehicle DNL	64	27	39
Calculate Road #1 DNL	64	Reset	

Add Road Source Add Rail Source	
Airport Noise Level	

Loud Impulse Sounds?

Combined DNL for all Road and Rail sources	0
Combined DNL including Airport	
Site DNL with Loud Impulse Sound	
Calculate Reset	

# **Mitigation Options**

If your site DNL is in Excess of 65 decibels, your options are:

- No Action Alternative: Cancel the project at this location
- Other Reasonable Alternatives: Choose an alternate site
- Mitigation
  - Contact your Field or Regional Environmental Officer (/programs/environmental-review/hud-environmental-staff-contacts/)
  - Increase mitigation in the building walls (only effective if no outdoor, noise sensitive areas)
  - Reconfigure the site plan to increase the distance between the noise source and noise-sensitive uses
  - Incorporate natural or man-made barriers. See *The Noise Guidebook (/resource/313/hud-noise-guidebook/)*
  - Construct noise barrier. See the Barrier Performance Module (/programs/environmental-review/bpm-calculator/)

## **Tools and Guidance**

Day/Night Noise Level Assessment Tool User Guide (/resource/3822/day-night-noise-level-assessment-tool-user-guide/)

Day/Night Noise Level Assessment Tool Flowcharts (/resource/3823/day-night-noise-level-assessment-tool-flowcharts/)